# Warranty Registration

Please mail or e-mail to warrantyreg@brightasslights.com -OR-

Submit online at: www.brightasslights.com within 30 days of purchase.

Dealer Name:			
Dealer Address:			
City:State:Zip:			
Customer Name:			
Address:			
City:State:Zip:			
Email:			
Serial#:(found on box or back of light)			
Date Purchased:			
Motorcycle Year:Make:			
Would you recommend our product to others?  [ ] Yes [ ] No			
Are there any features or functions you would like to see added or removed?  [ ] Yes [ ] No			
Comments:			

Cut Along Dotted Line & Mail

# Owner's Personal Record

(Keep for your reference)

Customer Name:			
Address:			
City:	_State	_Zip:	
Purchase Date:	_Model#:		
S/N:In:	stall Date:		
Motorcycle Info: Year:Make:			
Model:			
Dealer Name:			

For Technical Assistance Please Call 1-(866)-364-6690 or visit our website www.BrightAssLights.com

We're Proud,
All Of Our Products Are Designed &
Made in the USA!



PSI P.O. Box 730151 Ormond Beach, FL 32173

1-386-246-8737 www.BrightAssLights.com tech@brightasslights.com If you like our product, tell your friends!
If not, tell us!



Installation
Instructions
&
Warranty
Information

BAL-K-NMD-1

PSI P.O. Box 730151 Ormond Beach, FL 32173

1-386-246-8737 www.BrightAssLights.com tech@brightasslights.com

# PLEASE READ BEFORE INSTALLING

## **Tools Needed:**

Phillips Screwdriver

### Directions:

1- Unscrew Two Phillips Screws on Factory Tail Light And Remove Lens

2- Remove Both Light Bulbs

3- Insert Dummy Bulb into Left Socket

4- Insert New Light Base into Right Socket

5- Slide New LED Assembly in Between the 2 Posts (make sure not to pinch wiring)

6- Slide Included Rubber Mounts Down Each Post Until Firmly Seated

7- Reinstall Lens and Tighten 2 Screws Previously Removed in Step 1

(lens will be snug going back on)

\*\*Check Full Operation Before Riding\*\*

# **Using Brake Patterns:**

NOTE:Patterns can only be set when **BRAKE IS ON**. Use supplied Wire Tie to compress brake switch. (Just enough to trigger brake light and easy to remove) Keeping the end of the magnet with the red dot facing away from the motorcycle, slide the magnet along the seam of the lens where the red section and clear section join together. Observe pattern change. After setting pattern leave brake on for 5 seconds to store it.

# Changing Running Intensity:

With IGN on only, use magnet to change intensities.

# Alternate Option or for Remote Controllers:

Remove WHITE/VIOLET wire from sleeve & connect to momentary +12 Volts to change patterns. Every time +12Volts is applied & removed a new pattern will be selected. Let the light run the desired pattern for 5 seconds to store.

# See our website for additional information

Slide magnet across seam.

Keeping the center part of the magnet where the clear section and the red section join.



### **Brake Light Patterns**

Pattern/modes: (D) STEADY 12: (2) BRAKE TAP 7 (D) SIG-ALERT STEADY 13: (2) BRAKE TAP 8 (D) BRAKE TAP 14: PARADE MODE 1 (2) STEADY 2 15: PARADE MODE 2 (2) SIG-ALERT STEADY 16: PARADE MODE 3 (2) BRAKE TAP 2 17: PARADE MODE 4 (2) SIG-ALERT FLASH 18: PARADE MODE 5 (2) BRAKE TAP 3 19: PARADE MODE 6 (2) BRAKE TAP 4 20: PARADE MODE 7 (2) BRAKE TAP 5 21: PARADE MODE 8 (2) BRAKE TAP 6 22. PARADE MODE 9 23. PARADE MODE10

(D) Designates DOT/FMVSS Compliant Pattern(s) (2) Indicates Level 2 Intensities and are brighter than stock \*PARADE MODEs are not intended for continuous or night use\* \* Any other mode but (D) is for off road use \*

# **Tail Light Intensity Levels**

When Tail light is active (not brake)

LEVEL 1 (1%) (D)

LEVEL 2 (3%)

LEVEL 3 (10%)

Magnet placement is critical to sensing the magnetic field. This may take a few tries initially to become accustomed to proper alignment.

Please visit our website for more detailed information.

## *STAND BACK* to get the FULL Effect.

LED Lights seem brighter the farther away from the source. CAUTION!!

Our LED Lights are INTENSE!!

#### **PLEASE**

DON'T STARE INTO THEM!!

#### LIMITED 5 YEAR WARRANTY

PSI warrants the original consumer purchaser that the enclosed product is free from defects in material and workmanship. This is provided that the product has been installed and operated in accordance with the manufacturer's recommendations. During the warranty period the Factory Repair Center or an Authorized PSI Dealer will repair or replace (at its option) any parts or electronic assemblies of the unit which disclose a defect in material or workmanship, excluding lens. Product may be returned postage pre-paid to: PSI. 3000 E. Moody Blvd., Building 1, Unit C Bunnell, FL 32110 with copy of the purchase receipt or warranty registration on file. Warranty does not cover labor costs for removal and reinstallation of the unit for repair which is performed by the installer or dealer. This warranty is not applicable to any PSI product that has failed due to abuse, misuse, improper installation, excessive voltages, or alterations to the product that affects, in the manufacturer's judgment, intended use and service. PSI will not be held liable for any incidental or consequential damages and assumes no responsibility or liability for expenses incurred in the removal and/or reinstallation of products requiring service and/or repair: nor the packaging, handling and shipping to the Repair Center or Dealer. PSI reserves the right to modify this warranty statement at any time; or discontinue, modify or upgrade of it's manufacture with design improvements without prior notice. There are no other warranties, expressed or implied, including, but not limited to, any implied merchantability or fitness for a particular use. This warranty gives you specific rights, and you may also have other rights which vary from state to state.

Place Stamp Here

Cut Along Dotted Line & Mail

Ormond Beach, FL 32173-0151 P.O. Box 730151